

LAWRENCE TOWNSHIP DRIVEWAY INSTRUCTIONS
WHEN INSTALLING A CONCRETE DRIVEWAY IF THERE IS

CURBING AND GUTTERS THEN BUTT THE CONCRETE UP AGAINST
THE CURB. IF NO CURB THEN THE LAST THREE (3') FEET OF THE
DRIVEWAY TO THE ROADWAY HAS TO BE ASPHALT OR GRAVEL
/ LIMESTONE

(EXAMPLE)

